



Blood pressure measurement: Measure accurately

Screening for high blood pressure

- Use a validated, automated device to measure BP
- Use the correct cuff size on a bare arm
- Ensure the patient is positioned correctly

If initial blood pressure is elevated, obtain a confirmatory measurement

- Repeat above steps
- Ensure the patient has an empty bladder
- Ensure the patient has rested quietly for at least five minutes
- Obtain the average of at least three BP measurements

Evidenced-based tips for correct positioning

- Ensure the patient is seated comfortably with:
 - 1 Back supported
 - 2 Legs uncrossed with feet flat on the floor/ supported with a stool
 - 3 Arm supported with the BP cuff at heart level
- Remain quiet: No one should be talking during the measurement

